


## Connect S-Video/Audio or Video/Audio to switch inputs



Connect switch outputs to stereo, recording device, modulator, and/or TV